## **General Preferences:**

The following steps describe how to import and setup IDOT default General Preferences.

- 1. Download "Default General Preferences.brsx" from the IDOT Bridge Load Ratings website by clicking the link and extracting the resulting zip file.
- 2. Click the "Bridge Exporer" tab in the ribbon, click "Import", select and open the .brsx file.



3. Click the "General Preference Template" folder, click "IDOT Default" in the Details, click the ">" button, and import the data.

🔐 System Data Import			×
System data items: System Data System Data System Data Coad Combination Settings Template System Defaults System Defaults Seneral Preference Template Seneral Preference Template Custom Agency Fields Labels	Details: Name De: DOT Default IDC	Selected to export:	Import Close

- 4. The template will now be available in your currently active database, however it is not yet set as the default.
- 5. In order to set the "IDOT Default" General Preferences template as the default template used when new models are created, click the "View" tab in the Bridge Explorer ribbon and click "Configuration".

Br R										
BRIDGE	EXPLORER	BRIDGE	FOLDER	RAT	е тос	DLS	VIEW			
Refresh	🚱 Retrieve All 🚱 Retrieve Ne	I 🛱 Select ext 🗱 Select	t All t None : Selection	Sort By •	Select Columns	US	Customary	>	Library	Configuration
		Brid	age Explore	er view						
🏫 F. 💋 R	avorites Folder Recent Bridges	r								
🛛 🖃 🗡 🖊	All Bridges									

6. Double-click the "System Defaults" folder. Within the "General" tab, select "IDOT Default" from the "Default preference setting" dropdown. Click "Save" in the lower right corner and close the Configuration window.

8-R	CONFIGURATION	AASHTOWare Bridge Rating	? - 8
BRIDG	E EXPLORER CONFIGURATION		
942	🗇 🖄 🦁 🛌 🖄 🗖		
-25			
	Rename Delete New Open Delete Close Group User User		
	Manage		
	Comp     User       Manage     User       Manne     Manage       Varis     All Users       All Users     Manne Saturd       All Starts     Raining Unit Engineers       Access Privileges     Access Privileges       Access Privileges     Bridge Juscimitosation       Bridge Description     Bridge Description       Bridge Description     Description       Description     Bridge Description       Bridge Defails     Private Bridge Folders       Private Bridge Folders     Private Bridge Folders<	System Defaults     General   Bridge workspace   Superstructure analysis   Defaults     Agency name:   OT Default   OT Default   OT Default     Vultimedia server folde:   Include multimedia links in bridge export/import	
			Save Close

# System Defaults

Within the "System Defaults" folder referenced previously, several other settings need to be setup as shown in the following images.

tem Defaul	ts X					
General	Bridge workspace Superstructure ana	ysis Specifications	Substructure analysis	Tolerance	Custom agency fields	Rating tool
LRFD	DF applicability ranges					
2020	) AASHTO LRFD Ranges					
Comp	g live load distribution factor oute simple beam distribution factor based or D/ASD	:				
	AASHTO Standard Specifications for highway	bridges article 3.6.3				
	AASHTO Manual for bridge evaluation article	6B.6.2.2				
LF	D/ASD Distribution factor for exterior beams Use only lever rule for exterior beams					

em Defaults	n Defaults ×									
General	Bridge workspace	Superstructure analysis	Specifications	Substructure analysis	Tolerance	Custom agency fields	Rating too			
Default sy	vstem of units: US C	Customary								
▶ <mark>ft</mark>	0.010000									
in	0.1250000									
m	0.0030480									
mm	3.17500									
mi	0.01000									
km	0.01000									

## Preferences:

The following images show how to setup recommended Preference settings used by IDOT.



## Libraries & Analysis Templates:

Library and analysis template files are available on the IDOT Bridge Load Ratings website. The following steps describe how to import these files.

- 1. Download applicable library or analysis template file from the IDOT Bridge Load Ratings website by clicking the link and extracting the resulting zip file.
- 2. For libraries:
  - a. Click the "View" tab in the Bridge Explorer ribbon and click "Library".



b. Click the "Bridge Exporer" tab in the ribbon, click "Import", select and open the .brlx file.



c. Click the "Appurtenances", "Materials", "Prestress Shapes", or "Vehicles" folders as applicable, click the ">>" button, and import the data.

Brary Import				>	<
Library items:		Details:		Selected to import:	
Library Appurtenances Generic Generic Parapet	~	Name Description	> < >		
				Import Close	]

- 3. For analysis templates:
  - a. Click the "Bridge Exporer" tab in the ribbon, click "Import", select and open the .brsx file.



b. Click the "Analysis Event Template" folder, click "IDOT LFR/LRFR" in the Details, click the ">" button, and import the data.

Br System Data Import			×
System data items:	Details:   Name Des   IDOT LFR Sta	Selected to export:	Import

4. The libraries and templates will now be available in your currently active database.

### STEEL

(updated 6/9/2025)

LRFD	LRFR
Points of Interest	Points of Interest
Generate at tenth points	Generate at tenth points
Generate at section change points	Generate at section change points
Generate at user-defined points	Generate at user-defined points
Generate at stiffeners	Generate at stiffeners
Allow moment redistribution	Allow moment redistribution
Use Appendix A6 for flexural resistance	☑ Use Appendix A6 for flexural resistance
Allow plastic analysis	$\square$ Allow plastic analysis <sup>4</sup>
□ Ignore long. reinf in negative moment capacity	Evaluate remaining fatigue life
Consider deck reinf. development length <sup>1</sup>	Ignore long. reinf in negative moment capacity
□ Must consider user input lateral bending stress <sup>2,3</sup>	□ Include field splices in rating <sup>2,3</sup>
□ Consider concurrent moments in Cb calculation	Consider deck reinf. development length <sup>1</sup>
$\Box$ Consider only fully developed cover plates <sup>2</sup>	$\checkmark$ Consider tension-field action in stiffened web end <sup>3</sup>
LTB GammaE Method <sup>2,3</sup>	Must consider user input lateral bending stress <sup>2,3</sup>
Method A	Consider concurrent moments in Cb calculation
O Method B	✓ Use compact web alternate Cb calculation
Distribution Factor Application Method	$\Box$ Consider only fully developed cover plates <sup>2</sup>
O By axle	LTB GammaE Method <sup>2,3</sup>
By POI	Method A
	O Method B
LFR	Distribution Factor Application Method
Points of Interest	O By axle
Generate at tenth points	By POI
Generate at section change points	
Generate at user-defined points	ASR
Allow moment redistribution	Points of Interest
Allow plastic analysis of cover plates <sup>4</sup>	Generate at tenth points
Include field splices in rating <sup>2,3</sup>	Generate at section change points
Include bearing stiffeners in rating <sup>3</sup>	Generate at user-defined points
Allow plastic analysis <sup>4</sup>	Ignore long. reinf in negative moment capacity
Ignore long. reinf in negative moment capacity	Consider deck reinf. development length <sup>1</sup>
Ignore overload operating rating	$\Box$ Consider tension-field action in stiffened web end <sup>3</sup>
Ignore shear	□ Consider only fully developed cover plates <sup>2</sup>
$\blacksquare$ Consider deck reinf. development length <sup>1</sup>	Typical Additional Self-Load for Steel:
$\square$ Consider tension-field action in stiffened web end <sup>3</sup>	Diaphragm Load Specified in Framing Plan?
Consider only fully developed cover plates <sup>2</sup>	Girder Type     No     Yes       Bolled     10%     5%
Distribution Factor Application Method	Plate (w/o intermed. stiff.) 10% 5%
O By axle	Plate (w/ intermed. stiff.) 15% 10%
By POI	Built-Up 20% 15%

<sup>1</sup>Not used for Built-Up Members.

<sup>2</sup>Not used for Stringers.

<sup>3</sup>Not used for Floorbeams.

<sup>4</sup>Unchecked for riveted members, or when plans are missing, or when Fy > 70 ksi.

#### NORMALLY REINFORCED CONCRETE

(updated 6/9/2025)



<sup>1</sup>May be turned off for non-continuous superstructures.

<sup>2</sup>Not used for I-Beams & T-Beams.

<sup>3</sup>Not used for I-Beams.

<sup>4</sup>Ignore Shear for Slabs

#### PRESTRESSED CONCRETE

(updated 6/9/2025)



<sup>1</sup>May be turned off for non-continuous superstructures, e.g. simple span PPC deck beams.

<sup>2</sup>1979 Interim may be used for load rating purposes only, it must be turned off for special/limited crossing permit analysis.

#### **RC BOX CULVERT**

(updated 6/9/2025)



<sup>1</sup>Ignore Shear when fill height < 2.0'

#### **METAL PIPE CULVERT**

(updated 6/9/2025)

### LRFR

- Consider Duncan and Drawsky plastic moment
- Consider multiple loaded lanes
- ☑ Ignore effects from negligible LL

### LFR

- Consider Duncan and Drawsky plastic moment
- ☑ Consider multiple loaded lanes
- ☑ Ignore effects from negligible LL

## **BrDR Model Name Acronyms**

Acronym	1st Position	2nd Position	3rd Position	Long Name
	Iviateriai	Type/Snape	Configuration	
CBC	Concrete	Box	Continuous	Cast-In-Place Reinforced Concrete Roy Culvert Continuous
	Concrete	Box	Simple	Cast-In-Place Reinforced Concrete Box Culvert Simple
CPC	Concrete	Pigid Box	Continuous	Cast-In-Place Reinforced Concrete Box Culvert Simple
CRC	Concrete	Rigid Box	Single	Cast-In-Place Reinforced Concrete Rigid Box Culvert Single-Cell
	Drocast Consta	Rigid Box	Single	Drocast Painforced Concrete Rigid Box Culvert Single Cell
FIG	Frecast concrete	Nigiu Dox	Single	
CSC	Concrete	Slah	Continuous	Reinforced Concrete Slab Continuous
CSH	Concrete	Slab	Haunched	Reinforced Concrete Slab Haunched
CSS	Concrete	Slab	Simple	Reinforced Concrete Slab Simple
000	concrete	510.5	Simple	
СТС	Concrete	Tee Beam	Continuous	Reinforced Concrete Tee Beam Continuous
СТН	Concrete	Tee Beam	Haunched	Reinforced Concrete Tee Beam Haunched
CTS	Concrete	Tee Beam	Simple	Reinforced Concrete Tee Beam Simple
PCS	Precast Concrete	Channel Beam	Simple	Precast Reinforced Concrete Channel Beam
			•	
PDS	Prestressed Concrete	Deck Beam	Simple	Prestressed Concrete Deck Beam
PES	Prestressed Concrete	Spread Box Beam	Simple	Prestressed Concrete Spread Box Beam
		·	•	
PBC	Prestressed Concrete	Bulb-Tee Beam	Continuous	Prestressed Concrete Bulb-Tee Beam Continuous
PBS	Prestressed Concrete	Bulb-Tee Beam	Simple	Prestressed Concrete Bulb-Tee Beam Simple
PIC	Prestressed Concrete	I-Beam	Continuous	Prestressed Concrete I-Beam Continuous
PIS	Prestressed Concrete	I-Beam	Simple	Prestressed Concrete I-Beam Simple
PXC	Prestressed Concrete	IL-Beam	Continuous	Prestressed Concrete IL-Beam Continuous
PXS	Prestressed Concrete	IL-Beam	Simple	Prestressed Concrete IL-Beam Simple
SPC	Steel	Welded Plate Girder	Continuous	Steel Welded Plate Girder Continuous
SPS	Steel	Welded Plate Girder	Simple	Steel Welded Plate Girder Simple
SRC	Steel	<b>Riveted Plate Girder</b>	Continuous	Steel Riveted Plate Girder (Built-Up) Continuous
SRS	Steel	<b>Riveted Plate Girder</b>	Simple	Steel Riveted Plate Girder (Built-Up) Simple
STC	Steel	Truss	Continuous	Steel Truss Continuous
STS	Steel	Truss	Simple	Steel Truss Simple
SWC	Steel	Wide Flange Beam	Continuous	Steel Wide Flange Beam Continuous
SWS	Steel	Wide Flange Beam	Simple	Steel Wide Flange Beam Simple
TBC	Timber	Beam	Continuous	Timber Beam Continuous
TBS	Timber	Beam	Simple	Timber Beam Simple
TSC	Timber	Slab	Continuous	Timber Slab Continuous
TSS	Timber	Slab	Simple	Timber Slab Simple
MPS	Metal	Pipe	Simple	Corrugated/Spiral Rib/Structural Plate Metal Pipe Culvert