

Stockpile Management

PURPOSE:

Stockpile management procedures are designed to reduce or eliminate stormwater pollution from stockpiles of materials such as but not limited to uncontaminated soil, concrete, asphalt, and aggregate.

IMPLEMENTATION:

- The location of all stockpiles must be identified on the Storm Water Pollution Prevention Plan (SWPPP).
- Protection of stockpiles is a year-round requirement.
- Stockpiles are not to be located in areas of concentrated flows of stormwater or drainage ways. Stockpiles are to be located a minimum of 50 feet away from all drainage inlets.
- Perimeter erosion barrier should be used around all stockpiles to prevent sediment from leaving the stockpile site.
- Uncontaminated soil stockpiles must be covered or protected with soil stabilization measures.
- All temporary stockpiles of materials such as top soil, compost, and wood mulch which are delivered to the site should be incorporated the same day as delivery.

INSPECTION/MAINTENANCE:

- All stockpile locations are to be inspected every 7 calendar days and after a storm event of ½" or greater (including snowfall).
- Repair and/or replace perimeter erosion barrier and stabilization measures as needed to keep them functioning properly.
- Update the SWPPP anytime a stockpile location has been removed, relocated, added, or required maintenance.

NOTE:

- Contaminated soil stockpiles are to be handled according to Article 669.11 Temporary Staging in the standard specifications.